

ARCO

TOURNAMENT SHUFFLEBOARD DISCS

The National, International and State Shuffleboard Association Rules state: "**New discs are not to be used in Tournament Play unless thoroughly broken in.**" We recommend sanding because it greatly reduces the time of "break in". The discs enclosed are the results of many years of innovative improvements in Shuffleboard technology now offering you, the professional shuffler, the finest, chip resistant, balanced, easy to see, smooth running shuffleboard disc manufactured. These all new tournament discs "break in" slow on the courts; therefore we suggest you speed up the "break in" process by sanding the new discs as follows before using them in tournament play.

Use two (2) grits of sandpaper (production paper) or (wet and dry). 80 Grit (course) - 180 Grit (Medium) - 320 Grit (Fine).

- First Place the 80 Grit paper on a flat surface. Sand each disc by rubbing the bottom of the disc in a circular motion until flat.
- Second Sand each disc on the 180 Grit paper to remove the scratches.
- Third Sand each disc on the 320 Grit paper to finish and polish the disc.
- Fourth Apply a few lines of hard disc wax horizontally and vertically (checkerboard effect ) to the bottom of the disc. Apply a coat of hard wax to the outer rim of bottom of disc.

Discs are now ready for Official Tournament Play.

Sam H. Allen
Allen R. Shuffleboard Co. Inc.